


How to find the NVS-2X on an IP network

By default, once the physical connections have been made, the **NVS-2X will try to obtain an IP Address from a DHCP network server**. Please note that this can be changed to a Static IP address if required.

How to use the NVS-2X IP Finder utility software

Datavideo supplies a free, *Windows based* utility, called **NVS-2X IP Finder**.

The first time this software is used on the computer you may need to disable your computer firewall / anti-virus settings in order for it to be able to scan or search the local network.



When the utility scans the LAN that the computer is connected to, it displays the current IP address for any NVS units found on this local IP network. Double clicking on the device listed will automatically open your computers default web browser and navigate to the login page of the NVS device.

If you are using an Apple computer then you can use an alternative utility app such as Fing or Network Analyzer Lite.